

Moseley wiring instructions

- 1) Disconnect battery
- 2) Punch hole, right kick to front trunk
- 3) Mount relay strip in front trunk, right side
- 4) Pull "bundle" wires through
- 5) Rewire fuse panel
 - a. Rewire High beam
 - i. Remove heavy green wire from fuse 2
 - ii. Plug above wire to male spade of light green wire #4
 - iii. Plug heavy green wire #1 to fuse 2 terminal
 - b. Rewire Low Beam
 - i. Remove heavy gray wire from fuse 5
 - ii. Plug above wire to male spade of light gray wire #5
 - iii. Plug heavy gray wire #2 to fuse 5 terminal
 - c. Rewire Fan
 - i. Remove Heavy pink wires from fuses 11 and 12
 - ii. Plug above two wires to male spades of light pink wires #6 and #7
 - iii. Plug heavy pink wire #3 to fuse
- 6) Connect heavy red wire to amp meter, alternator side



