


FUSE 7
30A



KEY IN IGNITION WARNING BUZZER
(SELF-INTERRUPTING RELAY)

KEY WARNING DRIVER DOOR JAM SWITCH
(SWITCH SHOWN IN DOOR OPEN POSITION)

KEY IN IGNITION SENSOR SWITCH
(SWITCH SHOWN IN KEY IN IGNITION POSITION)

SOBill@aol.com 2 APR. '02

KEY IN IGNITION WARNING BUZZER